

Phone: 714-532-2798
Fax: 714-639-5325

CARLI SUSPENSION, INC.
2177 N. Batavia Suite A
Orange, CA 92865

Carli
SUSPENSION
www.TheCarliSuspension.com

SWAY BAR ENDLINK INSTRUCTIONS

1. Drill out the lower sway bar end link mount on the axle to ½". The mount is located off the front of the lower coil seat. NOTE: 06-08 no drilling is required. Use supplied reducers.
2. Assemble the new Stainless End links 1 ½" longer than stock.
3. Install Stainless End links onto truck with supplied hardware and tighten. You will connect to sway bar when truck is at ride height. Notice order of spacers and washers, from the outside in goes -bolt, washer, OEM mount, washer, spacer, heim end, spacer, washer, nut